

Assembling the Vibrobot:

1. Color your Makey and cut it out.
2. Stick the disc motor to the underside of the solar panel.
3. Use Maker Tape to connect red wire to the silver pad marked with a plus (+) sign.
4. Connect the blue wire to the silver pad marked with a negative (-) sign.
5. Add foam tape to the underside of the solar panel.
6. Attach the panel to the front of the robot template.
7. Expose to sunlight.

